

A

- abbreviations, 46
- about BSD CostLink/AE
 - command in help menu, 127
- ADD, 59
- adding commands, 96
- adding costs
 - user-defined, 67
- adjustments, 67
- Adobe Acrobat format
 - export reports to, 81
- aeLinkMan, 111
- arrange icons
 - command on window menu, 126
- arranging windows. *See* windows
- ASM, 59
- assemblies, 64
 - about estimating with, 8
 - example, 64
 - identifying members of, 61
 - item form, 58, 65
- Assemblies
 - resource window. *See* resource windows
- auto-recalculate markups
 - command on tools menu, 125

B

- base cost, 57, 60
- blue icon on folders or tasks, 40
- building perimeter, 54
- building size, 54

C

- calculator
 - open from Tools menu, 98
- cascade windows
 - command on window menu, 126
- change Excel links source, 125
- change RS Means database
 - command on tools menu, 126
- chapter summary

- user manual, vii
- child folder
 - command on insert menu, 125
- close
 - button on toolbar, 118
 - command in file menu, 121
- compact
 - command on file menu, 92
- compact database
 - command in file menu, 121
- company logo
 - insert on reports, 72, 81
- construction priced from R.S. Means, 68
- contents
 - command in help menu, 127
- context menus, 127
- contingencies
 - about the RS Means cost data, 7
- contractor fees, 70
 - how calculated, 70
- copy
 - button on toolbar, 119
 - command in edit menu, 122
 - command in file menu, 121
 - how to copy projects, 90
- copy and paste
 - how to, 64
- cost
 - cost to owner, 60
 - cost to prime, 60
 - project cost, 61
- Cost Estimate
 - without models, 18
- cost estimates, no model, 18
- cost model additives, applying, 15
- cost summary tab
 - summary information dialog box, 67
 - tips, 68
- cost to owner, 57
- cost to prime, 57
- CostLink/AE
 - adding costs, 22
 - adding folders, 20
 - applying markups, 16
 - creating model project file, 12

- overview, 2
- printing reports, 33
- project notes, 19
- tools and techniques, 84
- costs. *See also* RS Means Cost Data
 - abbreviations list, 129
 - adding lump sum quote, 67
 - adding to estimate, 61
 - adjustments, 67
 - base cost, 57
 - change reference database, 99
 - changing, 60
 - copying into projects, 63
 - cost to owner, 57
 - cost to prime, 57
 - fees, 67
 - markups, 67
 - per unit cost for folders, 57
 - per unit cost for project, 51
 - project cost, 58
 - show in reports, 74
 - show in tree panel, 42
 - updating, 98
 - viewing on tasks, 58
- costs, adding, 22
- create a new project
 - button on toolbar, 118
- creating a project, 49
- creating an estimate, 49
- CSI MasterFormat and UniFormat, 49
- custom reports, 77
- customize tools menu, 96
 - command on tools menu, 126
- customizing display, 38
- customizing toolbars, 94
- cut
 - button on toolbar, 118
 - command in edit menu, 122

D

- database windows, 38
- delete
 - button on toolbar, 119
 - command in edit menu, 122
- delete empty folders, 90
 - command on tools menu, 126
- delete link from source
 - command in LinkMan menu, 125
- detail estimate report, 80
- detailed estimate, 74
- direct costs

- adding to estimate, 61
- disable updating from sources
 - command on LinkMan menu, 125
- down one level
 - command in tree menu, 123
- drag & drop confirmation, 126
- drag and drop, 89
 - how to, 63
 - left mouse button vs. right, 89
 - turn off confirmation prompt, 89
- drill-down tabs
 - in print preview, 79

E

- edit menu, 122
- effective pricing date, 51
- electronic copies of reports
 - creating, 81
- emailing estimates, 81
- equipment costs
 - about the RS Means cost data, 5
- escalation
 - about the RS Means cost data, 7
- escalation index date, 51
- estimate. *See also* projects
 - creating, 49
 - date of, 51
 - opening, 48
- estimated construction time, 51
- estimates
 - emailing, 81
- estimating
 - checklist, 7
- Excel. *See* linking to Excel
- exit
 - command in file menu, 122
- expand all
 - command in tree menu, 124
- expand branch
 - button on toolbar, 120
 - command in tree menu, 124
- export
 - reports, 81
- exterior closure and framing, 54

F

- fees, 67
 - contractor, 70
- file menu, 121
- file name and path, 51

file size
 compacting, 92

find
 button on toolbar, 118
 command in edit menu, 123
 how to use, 84

folder
 command on insert menu, 124

folder icon, 40

folder tags
 show in tree panel, 42

folders, 56
 buttons on, 58
 how to copy or move, 88
 item form, 57
 opening item form, 56
 printing options, 75
 tags, 57

folders, adding, 20

footer
 on reports, 76

formatting reports, 75

G

general conditions
 about the RS Means cost data, 5

general tab
 project folder form, 57
 Summary Info dialog box, 14
 summary information dialog box, 50

go to folder
 command in tree menu, 124

green icon on folders or tasks, 40

green square Excel icon, 102

H

help
 contents tab, 44
 index, 127
 index tab, 45
 printing, 45
 search, 127
 search tab, 46
 searching, 45, 46

help menu, 127

cut, 88

paste, 88

I

icons
 list of and descriptions, 40

index tab, 127
 help dialog box, 45

insert menu, 124

installation instructions
 where to find, vii

L

labor costs
 about the RS Means cost data, 5

launching other programs, 96

line items, 66
 adding your own, 67
 item form, 58

linking
 change Excel links source, 115
 delete link from source, 114
 disable updating from sources, 115
 parent quantity, 103
 paste link from source, 114
 refresh all links from sources, 114
 remove all links from sources, 115

linking to Excel
 Excel comments, 111
 Excel features used, 111
 Excel icon on folders and tasks, 40
 overview of steps, 112
 parameter workbook characteristics, 110
 range names, 111
 setup, 105
 sheet names, 110
 software requirements, 104
 tips, 113

LinkMan menu, 125

load from compressed
 command in file menu, 121
 command on file menu, 93

location adjustment
 about the RS Means cost data, 6
 Canada, 69
 how to enter, 69

locking a form, 58

logo
 insert on reports, 72, 81

M

markups, 67

markups, applying, 16
MasterFormat, 49
material costs
 about the RS Means cost data, 4
MDL, 59
Means Costs. *See* RS Means Cost Data
menus, 120
 context, 127
 edit, 122
 file, 121
 help, 127
 insert, 124
 LinkMan, 125
 right-click, 127
 tools, 125
 tree, 123
 view, 123
 window, 126

Microsoft Excel. *See* linking to Excel
minus sign icon, 40
model

 disconnecting from, 60
 model building parameters, 54
 model costs
 about the RS Means cost data, 4
Model Estimate

 applying additives, 15
 cost models tab, 15
 model estimate, creating, 15
 model project file, creating, 12
 model workbooks. *See* linking to Excel
models

 Uniformat II project template with models,
 53, 55

move
 how to move folders and tasks, 88
moving the software
 where to find instructions, vii

N

navigation, 41
new project
 command in file menu, 121
new window
 command on window menu, 126
notes, 86
 blue icon on folders or tasks, 40
 printing on reports, 76, 87
 spell check, 53
 viewing, 87
notes window

 command in view menu, 123

O

O&P
 about the RS Means cost data, 5
open
 command in file menu, 121
open assemblies resource window
 button on toolbar, 120
open help to contents
 button on toolbar, 120
open item form on the Sheet panel
 button on toolbar, 119
open item form on the Tree panel
 button on toolbar, 119
open recently used projects dialog
 button on toolbar, 118
open the notes form
 button on toolbar, 119
open the summary info dialog
 button on toolbar, 119
open unit prices resource window
 button on toolbar, 120
open windows list
 in window menu, 127
opening a project, 48
opening an estimate, 48
organization name
 on reports, 73
other costs, 70
overhead and profit
 about the RS Means cost data, 5
overtime
 about the RS Means cost data, 6

P

panels
 arranging, 38
parameter workbooks. *See* linking to Excel
parameters
 adjustable, 55
 model building, 54
parameters, fixed, 54
parent quantity
 linking to, 103
paste
 button on toolbar, 119
 command in edit menu, 122
paste link from source
 command on LinkMan menu, 125

pdf
 export reports to, 81
 permissions
 command in file menu, 122
 pictures, 86
 supported graphics file types, 87
 viewing, 87
 plus sign icon, 40
 preferences tab
 reports dialog box, 75
 preparation date, 51
 preview
 buttons in window, 79
 reports, 78
 print
 command in file menu, 121
 print percent of parent to level, 76
 print preview
 command in file menu, 121
 print selected report
 button on toolbar, 118
 print selected report to preview window
 button on toolbar, 118
 print setup
 command in file menu, 121
 productivity
 about the RS Means cost data, 6
 project
 delete empty folders, 90
 project cost, 58
 project description, 51
 project notes, 19
 project tasks. *See* tasks
 project title, 51
 projects, 48
 archiving, 93
 compacting, 92
 copying, 90
 cost models, 53
 cost models tab in summary information
 dialog box, 53
 creating, 49
 emailing to one who has CostLink/AE, 93
 model additives, 55
 model additives tab in summary information
 dialog box, 55
 notes, 52
 notes tab in summary information dialog box,
 52
 opening, 48
 saving and loading to compressed, 93
 summary information, 50

prompt before completing drag
 command on tools menu, 126
 pull-down menus, 120

Q

qty
 quantity field, 102
 quantity
 options for entering or calculating, 102
 project folders, 57
 use formula value times, 60
 use MS Excel value times, 57, 60
 use parent quantity times, 57
 use parent quantity times, 60
 use quantity entered, 57, 60
 quotes
 adding as line item, 67

R

R.S. Means cost data
 abbreviations list, 129
 about annual updates, 98
 change R.S. Means database, 99
 recalculate all
 command on tools menu, 125
 recalculate the current project
 button on toolbar, 118
 recently opened databases
 listed in file menu, 122
 recently used dialog box, 48
 refresh all links from sources
 command in LinkMan menu, 125
 remove all links from Sources
 command on LinkMan menu, 125
 report setup
 command in file menu, 121
 reports, 72
 Acrobat format, 81
 add company logo, 72
 change project title, 51
 create pdf file from, 81
 creating electronic copies, 81
 custom, 77
 descriptions of, 80
 detail, 80
 detailed estimate, 74
 dialog box, 72
 drill-down tabs, 79
 exporting, 79, 81
 folder options, 75

- footer, 76
- formatting, 75
- header, 74
- overview, 72
- previewing, 78
- print with or without markups, 74
- printing notes, 76, 87
- producing, 72
- selecting, 73
- summary, 74, 80
- table of contents, 74
- title page, 74
- unit cost column, 75
- reports, selecting and printing, 33
- resource windows, 62
 - abbreviations on tasks, 129
 - opening, 62
- right-click menus, 127
- RS Means abbreviations, 46
- RS Means cost data
 - contacting RS Means, 8
 - factors affecting costs, 5
- RS Means Cost Data
 - explanation of costs, 3
- RSM, 59

S

- sales tax
 - how to enter, 69
- save as
 - copy project instead, 90
- save to compressed
 - command in file menu, 121
 - command on file menu, 93
- search tab, 127
 - help dialog box, 46
- searching
 - using find, 84
- select all tasks
 - command in edit menu, 123
- select and format reports
 - button on toolbar, 118
- select model
 - commercial, 54
 - industrial, 54
 - institutional, 54
 - none, 54
- sheet items form
 - command in view menu, 123
- sheet panel
 - command in view menu, 123

- controlling display, 42
- icons, 41
 - sorting data, 43
- show all folders
 - button on toolbar, 120
- show data in tree
 - command in tree menu, 124
- show folder data in tree
 - button on toolbar, 120
- show folder tags, 42
 - button on toolbar, 120
 - command in tree menu, 124
- show hierarchy
 - command in tree menu, 124
- single tab mode, 39
- software requirements
 - for linking to Excel, 104
- sorting data
 - in sheet panel, 43
- source tag, 59
- spell check
 - project notes, 53
- stack windows in cascade
 - button on toolbar, 120
- standard toolbar, 118
- status bar
 - command in view menu, 123
- subscription
 - includes annual updates of cost data, 98
- summary info
 - command in file menu, 121
- Summary Info
 - general tab, 14
- summary information dialog box, 50
 - cost models tab, 53
 - cost summary tab, 67
 - model additives tab, 55
 - project notes tab, 52
 - Unifomat II project template with models, 53, 55
- summary report, 80
- system requirements
 - where to find, vii
- systems estimating. *See assemblies*

T

- table of contents, 74
- tabs
 - choosing single or multiple, 39
- tags
 - on folders, 57

- task
 - command on insert menu, 125
 - tasks
 - abbreviations list, 129
 - adding to estimate, 61
 - assembly members, 61
 - buttons on item form, 61
 - copying into projects, 63
 - how to copy or move, 88
 - identifying if assembly or line item, 59
 - item forms, 58
 - opening item forms, 58
 - templates, 49
 - tile horizontally
 - command on window menu, 126
 - tile vertically
 - command on window menu, 126
 - tile windows horizontally
 - button on toolbar, 120
 - tile windows vertically
 - button on toolbar, 120
 - tiling windows. *See* windows
 - title page, 74
 - toolbar, 118
 - toolbars
 - command in view menu, 123
 - customizing, 94
 - tools menu, 125
 - customizing, 96
 - tree items form
 - command in view menu, 123
 - tree menu, 123
 - tree panel
 - command in view menu, 123
 - controlling, 41
 - icons, 40
 - show folder tags, 42
 - showing costs, 42
- U**
- uniformat II, 8
 - UniFormat II, 49
 - unit cost
 - column on reports, 75
 - Unit Prices resource window. *See* resource windows
 - UOM, 57
 - up one level
 - command in tree menu, 123
 - update RS Means database
 - command on tools menu, 126
 - updating
 - to new R.S. Means costs data, 98
 - use formula value times, 102
 - use MS Excel value times, 102
 - use parent quantity times, 102
 - use quantity entered, 102
 - use single tab
 - command in tree menu, 124
 - use single tab for table
 - button on toolbar, 119
 - user manual
 - chapter summary, vii
 - send suggestions and corrections, viii
 - USR, 59
- V**
- view menu, 123
- W**
- WBS, 49
 - window menu, 126
 - windows
 - arranging, 38
 - tiling, 38
 - tips for using tile and cascade, 39
 - working with multiple, 38
 - with horizontal panels
 - command in view menu, 123
 - command in View menu, 38
 - with vertical panels
 - command in view menu, 123
 - command in View menu, 38

