

#

#, sequence number status column, 86

A

active files list, 66
active text, 103
active vs. inactive, 88
add new section from RTF file, 114
added text
 compare projects, 188
addenda
 preparing in PerSpective, 34
 using compare for, 188
adding folders, 109
adding links, 177
adding new sections, 110, 114
adding page breaks, 212
adding tables
 how to insert a table, 158
Adobe Acrobat
 use to create pdf files of sections, 230
align left, 84
align right, 84
alignment
 text properties, 201
allow BSD to publish project data, 99
alternate left/right header/footer, 205
apply master paragraph updates to project, 265
 preserve and mark deleted paragraphs, 265
applying tabs to paragraphs, 159
archiving, 234
 making backups, 234
 to tape, 235
arrange icons, 66
asterisks in the table of contents report, 224
auto numbering, 128
 turning off for imported tables, 158
auto-select new paragraphs, 65
 command in tools menu, 154

B

background color
 status columns, 87
backing up, 234
 to tape, 235
blackline, 188
blue
 background color of status column, 87
 in header/footer dialog box, 209
 significance, 133
 text color in document panel, 129
bold, 84
bookmark, 63, 130
border, 85
borders on tables, 66
branch
 demote, 149
 promote, 149
BSD SpecLink. *See* SpecLink

C

cascade windows, 66
center, 84
certificate requirements report, 212
changing columns in a table, 66
check out | check in
 about, 237
checklists, 251
 adding pictures, 253
 and tags, 250
 examples, 251
 tips on adding non-printing text, 252
checkmark, 87
child, 132
choice group type, 162
choice links, 181
choices, 134
 choosing, 137
 color, 129
 editing, 165
 embedded, 129
 exclusive multiple, 135
 fill-in the blank, 136, 137
 global, 137

 inclusive multiple, 136
 making choices, 137
 MasterFormat version choice, 164
 optional, 162
 overview, 134
 removing, 166
 types, 134
 unit of measure, 164
 user-added, 161
 viewing, 134
close project, 56
 button on toolbar, 67
gray, 88
color printing
 reports dialog box, 220
colors
 blue, significance, 133
 dark gray, significance, 132
 definition, 132
 green, significance, 134
 light gray, significance, 132
 magenta, significance, 134
 red, significance, 134
 rust, significance, 134
 yellow, significance, 134
columns
 page layout, 204
communications
 using SpecLink tab for, 47
compact project, 233
compact view, 138
compare projects, 188
 added text, 188
 concepts, 188
 deleted text, 188
 deselected text, 188
 edited text, 188
 excluded text, 188
 how to, 189
 printing, 192
 use for addenda in PerSpective, 34
 use in RFP process, 26
 viewing, 191
copies
 reports dialog box, 221
copy, 152
 copy section for pasting dialog box, 118
 sections, 118

- sections within a project, 118
- copy project, 56
- copying
 - paragraphs, how to, 153
- copying tables
 - importing from Word, 156
- creating new sections, 110
- creating projects, 94
- CT tag, certificate requirements report, 212
- customize footer, 207
- customize header, 207
- customizing styles, 200

D

- dark gray
 - significance, 132
- DC tag, design calculations requirements report, 213
- default printer, 218
- default terms
 - replacement, 98
- delete a row in a table, 66
- delete project, 56
- delete selected section, 121
- delete table, 159
- delete table column, 66
- deleted sections, 264
- deleted text
 - compare projects, 188
- deleting
 - choices, 166
 - links, 184
- demote branch, 64, 149
- demote button, 149
- demote paragraph, 149
- demoting
 - break in level hierarchy message, 149
- deselecting sections, 103
- design build use, 20
- design calculations requirements report, 213
- design-bid build use, 20
- design-bid-build projects
 - how is it used?, 3
- design-build projects
 - how is it used?, 2
- dictionary, 64
- differences from word processing, 10
- display sequence numbers, 71
- DL, document links status column, 86
- Do Not Apply Master Paragraph Updates To Project, 266
- document links (DL), 86

- document menu, 61
 - add choice, 62, 161
 - add new section, 62
 - add new section from RTF file, 62
 - add paragraph, 61
 - check out | check in, 63
 - choices, 62
 - copy section, 62
 - cut section, 62
 - delete selected section, 63, 121
 - demote, 64
 - demote branch, 64
 - edit choice, 62
 - insert page break, 62
 - mark place, 63
 - no autonumber, 63
 - paste section into, 63
 - promote, 64
 - promote branch, 64
 - remove choice, 62
 - remove document link, 61
 - remove page break, 62
 - remove paragraph, 61
 - restore paragraph from master (or project), 61
 - return to mark, 63
 - sections, 62
 - show text levels, 63
- document panel, 127
 - illustrated, 82
 - paragraphs, 82
 - ruler, 85
 - status columns, 82, 86
 - toolbar, 83
- double-side printing, 204
- down one level, 60
- draft copy, 218

E

- edit
 - how to, 146
- edit menu, 57
 - copy, 58
 - cut, 57
 - delete, 58
 - find, 58
 - paste, 58
 - undo last edit, 57
- edit toolbar, 71
- edited text
 - compare projects, 188
- editing
 - choices, 165
 - master text, 147
 - paragraphs, 146
 - project text, 147

- with multiple users, 76, 104
- edits
 - deleting, 147
- email sections
 - create PDF files, 230
 - create rtf files, 230
- excluding text, 130
 - how to, 131
- exclusive multiple choices, 135
- exit, 57
- expand all, 61
- expand branch, 61
- expand to, 61
- expert view, 138
- export, 228
 - reports dialog box, 221
 - to rtf, 228
 - to word processor, 228
- extra materials requirements report, 213

F

- field report requirements report, 213
- file menu, 55
 - close project, 56
 - copy project, 56
 - delete project, 56
 - exit, 57
 - load from zip file, 56
 - new project, 55
 - open project, 55
 - page setup, 57
 - print, 57
 - print preview, 57
 - registration and settings, 57
 - rename project, 56
 - repair/compact aecLinkMan, 56
 - repair/compact project, 56
 - save to zip file, 56
 - summary info, 56
- fill-in the blank
 - choice group, 136
 - replace in choice group, 136
 - stand-alone, 136
- find, 58
 - button on toolbar, 68
- folders
 - adding, 109
 - deleting, 109
 - renaming, 109
- font, 84, 202
 - dialog box, 202
- font size, 84
- fonts
 - customizing, 200
- fonts tab, 202

- footer, 206
 - alternate left/right, 205
 - defaults, 208
 - dialog box, 207
 - keywords, 209
 - using, 206
 - format
 - page layout, 194
 - specification options, 194
 - formatting choices for import, 117
 - FR tag, field report requirements report, 213
 - from edge settings, 204
 - FT tag, independent agency field testing requirements report, 213
- G**
- global choices, 137
 - global settings
 - establishing, 96
 - go to folder, 61
 - graphics in notes, 253
 - gray
 - background color of status column, 87
 - in tree panel, 76, 104
 - text in tree panel, 238
 - green
 - background color of status column, 87
 - significance, 134
 - green square status box, 88
- H**
- header, 206
 - using, 206
 - header/footer
 - alternate left/right, 205
 - defaults, 208
 - dialog box, 207
 - keywords, 209
 - help
 - accessing, 91
 - using, 91
 - help menu, 66
 - contents, 66
 - search for help on, 67
 - use index for help on, 67
 - hyperlinks, 247, 254
 - from SpecLink to Word, 255
 - hyperlinks to manufacturers, 8, 145
 - hyperlinks to reference standards, 9, 145
- I**
- IHS, 145
 - II tag, installation instructions requirements report, 213
 - import from clipboard, 154
 - how to, 156
 - import from project
 - copying section into a project, 122
 - importing choices, 117
 - importing from word processor, 154
 - asterisks, 155
 - blank lines, 155
 - indents, 155
 - levels, 155
 - line breaks, 155
 - notes, 155
 - numbering, 155
 - paragraph numbers, 155
 - paragraphs, 155
 - tabs, 155
 - in memory linking, 65
 - in use by
 - message in tree panel, 238
 - tree panel, 76, 104
 - include page count in toc report reports dialog box, 220
 - inclusive multiple choices, 136
 - independent agency field testing requirements report, 213
 - in-memory linking, 65
 - insert child folder, 109
 - insert folder, 109
 - insert row into table, 66
 - insert table, 66
 - inserting page breaks, 212
 - inserting tabs, 59
 - installation instructions
 - where to find, 12
 - Installation Instructions requirements report, 213
 - installer qualifications requirements report, 213
 - IQ tag, installer qualifications requirements report, 213
 - italic, 84
- J**
- justify, 84
- K**
- key icon
 - in tree panel, 238
 - keywords, 209
- L**
- date, 210
 - division ID, 209
 - division name, 209
 - font color, 209
 - footers, 209
 - headers, 209
 - page count, 210
 - page number, 210
 - project ID, 210
 - project location, 210
 - project name, 210
 - section ID, 209
 - section name, 210
 - time, 210
 - KW tag, 250
- L**
- LEED projects
 - how is it used?, 4
 - LEED Report requirements report, 213
 - level (LVL), 86
 - light gray
 - significance, 132
 - line numbering
 - reports dialog box, 221
 - link sources, 170
 - link sources tab, 171
 - link targets, 170
 - link targets tab, 172
 - LinkLine newsletter, 262
 - links, 170
 - adding, 177
 - between sections, 170
 - between sections of the PerSpective tab, 176
 - between sections of the SpecLink tab, 176
 - between the PerSpective, Short Form and SpecLink tabs, 177
 - button, 171
 - button on toolbar, 70
 - color, 175
 - concepts, 170
 - considerations, 175
 - deleting, 184
 - from choices, 180
 - from choices to choices, 183
 - from choices to paragraphs, 181
 - from paragraph to paragraph, 177
 - from paragraphs to choices, 182
 - from section to section, 180
 - how to add, 177
 - how to add from choices, 180
 - how to add from choices to choices, 183

- how to add from paragraphs to choices, 182
 - influence, 172
 - link sources, 170
 - link sources tab, 171
 - link targets, 170
 - link targets tab, 172
 - overriding master links, 185
 - overview, 170
 - paragraph, 173
 - section number, 173
 - sequence number, 173
 - source, 173
 - source influences, 174
 - specification, 173
 - target, 173
 - target influences, 174
 - types of influences, 173
 - viewing, 171
 - window, 171
 - window information, 172
 - within section, 170
 - load from zip file, 235
 - log file, 268
 - look for choice fields in import
 - command in tools menu, 154
 - look for choice fields on import, 117
 - LR tag, LEED Report requirements report, 213
 - LVL, level status column, 86
- M**
- magenta
 - significance, 134, 266
 - make project backup before updating, 268
 - making the transition from word processing, 46
 - manufacturer listings requirements report, 213
 - manufacturer qualifications requirements report, 213
 - margins, 204
 - mark place, 63, 71, 130
 - master notes, 102
 - master project file
 - adding checklists, 248
 - adding hyperlinks, 247, 254
 - adding links, 247
 - adding notes, 246
 - adding references, 251
 - adding sections, 246
 - adding text, 246
 - copy, 247
 - creating format master, 243
 - creating section masters, 244
 - file size, 242
 - import word processing files, 246
 - importing from clipboard, 247
 - methods of developing, 242
 - moving text, 247
 - overview, 242
 - paste, 247
 - project settings, 248
 - setting the default, 256
 - types of, 243
 - updates, 258
 - using, 245
 - master text copy, 219
 - master view, 138
 - MasterFormat, 7, 111
 - MasterFormat 2004, 80
 - MasterFormat 95, 78
 - MasterFormat Version
 - establishing format, 99
 - menu
 - file, 55
 - menu bar, 54
 - meter account printing, 226
 - methods of construction in PerSpective, 29
 - MF-04 Section ID Format, 99
 - mirror margins, 204
 - ML tag, manufacturer listings requirements report, 213
 - MO tag, mock-up requirements report, 213
 - mock-up requirements report, 213
 - modify paragraph format
 - choosing a predefined style, 201
 - level, 201
 - numbering style, 201
 - styles tab, 201
 - user defined style, 201
 - modify paragraph format, dialog box
 - font, 202
 - text properties, 201
 - move section, 120
 - move to buttons, 129
 - moving the software
 - where to find instructions, 12
 - MQ tag, manufacturer qualifications requirements report, 213
 - MT tag, 250
 - multiple windows, 127
- N**
- N, notes status column, 86
 - icons in, 102
 - naming projects, 94
 - navigation
 - section, 129
 - network installation
 - editing with multiple users, 76, 104
 - new project, 55
 - button on toolbar, 67
 - new window, 66, 127
 - no autonumber, 211
 - None – N/A, 136
 - non-printing text
 - adding non-printing text, 252
 - notes
 - adding, 146
 - editing, 146
 - icons, 144
 - master notes panel, 143
 - overview, 145
 - panels, 102, 143
 - project notes panel, 143
 - using, 145
 - using in tree panel, 145
 - using within a section, 146
 - viewing, 102
 - notes (N), 86
 - NP tag, 250
 - NS tag, 250
 - number format, 201
 - numbering
 - turning off, 211
- O**
- O, origin status column, 86
 - icons, 146
 - OM tag, operation and maintenance data requirements report, 213
 - open new window
 - button on toolbar, 69
 - open project, 55
 - button on toolbar, 67
 - opening existing projects, 105
 - operation and maintenance data requirements report, 213
 - orange
 - significance, 266
 - organization
 - performance sections, 23
 - orientation, 205, 222
 - origin (O), 86
- P**
- page breaks
 - inserting, 212
 - page range
 - reports dialog box, 220

- page setup, 203
 - alternate left/right header/footer, 205
 - dialog box, 203
 - duplex printing, 204
 - edge settings, 204
 - margins, 204
 - mirror margins, 204
 - orientation, 205
 - reports dialog box, 221
 - start document on odd page, 204
 - two column layout, 204
- PageFormat, 7
- paper options, 222
- paragraph format
 - changing, 200
 - customizing, 200
- paragraph numbering
 - turning off, 211
 - turning off for imported tables, 158
- paragraphs
 - adding, 148
 - auto-select new, 65
 - copying, 152
 - deleting, 148
 - deleting edits, 147
 - deleting, how to, 151
 - demote, 149
 - editing, 146
 - paste, 152
 - promote, 149
 - removing edits, 147
- parent, 132
- paste, 152
- pasting
 - paragraphs, how to, 153
- PD tag, product data submittals requirements report, 214
- PDF files
 - create, 230
- PE tag, professional engineer design requirements report, 214
- performance specification elements, 23
- performance specifications, 20
- PerSpective
 - design-bid-build system description, 38
 - introductory information, 26
 - origins, 18
 - recommended workflow, 21
 - system description, 25
- PerSpective document function, 100
- PerSpective hierarchy, 81
- PerSpective program
 - preparing, 32
- PerSpective RFP
 - preparing, 29
- PerSpective section organization, 23
 - methods of construction, 29
 - products, 29
- PerSpective Short Form section contents, 326
- PerSpective Short Form tab, 42
- PerSpective tab, 20
- PerSpective tab section content summaries, 277
- PerSpective tab section listing, 273
- PerSpective table of contents
 - preparing, 32
- PI tag, pre-installation meeting requirements report, 213
- pictures
 - adding to specifications, 253
- PR tag, project record documents requirements report, 214
- pre-installation meeting requirements report, 213
- Preparing RFQ in PerSpective, 31
- preview, 142
 - compact view, 216
 - overview, 216
 - print, 216
 - reports dialog box, 221
 - using, 142
- print
 - reports dialog box, 221
- print branch
 - reports dialog box, 220
- print log file, 268
- print preview, 216
 - button on toolbar, 67
- print preview, window, 216
 - options, 217
- print project
 - reports dialog box, 220
- print reports cover sheet
 - reports dialog box, 221
- print section
 - reports dialog box, 220
- print setup
 - orientation, 222
 - paper options, 222
 - printer selection, 222
- print table borders
 - reports dialog box, 221
- printer selection, 222
- printer setup
 - reports dialog box, 221
- printing, 194
 - default printer, 218
 - in color, 220
- master notes, 220
- page layout, 194
- project notes, 220
- reports dialog box, 217
- specifications, 226
 - using, 226
 - with a meter account, 226
- product data submittals requirements report, 214
- products in PerSpective, 29
- professional engineer design requirements report, 214
- program in PerSpective
 - separate document, 32
- project compression, 235
- project id, 97
- project maintenance
 - archiving projects, 234
 - backing up projects, 234
 - compacting projects, 233
 - tools, 232
 - updates, 260
 - zipping a project, 235
- project management tools, 212
- project manual
 - format and text, 26
 - project name, 97
- project notes, 59, 102
- project record documents requirements report, 214
- project source, 95
 - changing the default, 256
- project window, 52
 - menu bar, 55
 - overview, 52
 - tree panel, 75
- project window toolbar, 73
- projects
 - compare, 188
 - copying, 107
 - creating, 94
 - how to create, 94
 - how to open, 105
 - open existing, 105
 - open sample project, 51
 - overview, 102
 - previewing, 138
 - recently used dialog box, 105
 - reusing to improve productivity, 106
 - using as templates, 95
 - viewing, 138
- promote branch, 149
- promote button, 149
- promote paragraph, 149
- proposal documents
 - completing in PerSpective, 36
 - preparing in PerSpective, 34

proprietary sections in SpecLink,
47

Q

QS tag, qualifications statement
requirements report, 214
qualifications statement
requirements report, 214

R

RE tag, 249
rebuild project links, 66
rebuild section links, 65
recently used projects, 105
red
 significance, 134
red key
 in tree panel, 238
red stop sign
 significance, 88
redline, 188
Reference Standards on Demand,
145
references, 98
 adding to the master project file,
 251
 and tags, 249
 chapter 00840, 100
 consolidated list, 98
 print edition dates, 98
 section 01425, 98
references in PerSpective, 100
registration
 button on toolbar, 68
registration and settings, 57
related sections
 and tags, 249
remove choice, 166
rename project file, 56
repair/compact aeclinkMan, 56
repair/compact project, 56
replaceable terms
 hints, 101
report cover sheet, 212
report cover sheet tab, 99
report to print, 218
reports
 export, 221
 preview, 221
 print, 221
 report cover sheet, 212
 requirements, 212
reports cover sheet, 221
reports dialog box
 color printing, 220

copies, 221
 default printer, 218
 draft copy, 218
 export, 221
 include page count in toc report,
 220
 line numbering, 221
 master text copy, 219
 options, 218
 page range, 220
 print branch, 220
 print in color, 220
 print master notes, 220
 print project, 220
 print project notes, 220
 print reports cover sheet, 221
 print section, 220
 print table borders, 221
 printer setup, 221
 report to print, 218
 requirements reports, 219
 scope of report, 220
 table of contents, 219
 widow/orphan protection, 220
reports setup, 67
request for proposal in
 PerSpective, 26
closeout phase, 215
construction documents phase,
215
design development phase, 215
preliminary design phase, 214
proposal phase, 214
warranty, executed, 214
warranty, specimen, 214
construction phase, 215
occupancy phase, 215
requirements reports, 8, 212, 219
 hints, 215
 scope of report, 220
restore paragraph from master (or
 project), 61
return to mark, 63, 130
RFP
 preparing in PerSpective, 29
 responding in PerSpective, 35
RFQ preparation in PerSpective,
31
right mouse button
 document panel, 75
 tree panel, 74
RS tag, 249
RT tag, 249
rft files
 create, 230
ruler
 document panel, 85
 set margins, 85

rust color
 significance, 134, 266

S

S, status, one of the status
 columns, 87
S1 tag, proposal phase
 requirements report, 214
S2 tag, design development phase
 requirements report, 215
S2 tag, preliminary design phase
 requirements report, 214
S4 tag, construction documents
 phase requirements report, 215
S5 tag, construction phase
 requirements report, 215
S6 tag, closeout phase
 requirements report, 215
S7 tag, occupancy phase
 requirements report, 215
SA tag, samples requirements
 report, 214
samples requirements report, 214
save in-memory linking, 65
save to zip file, 235
scope of report
 document selection, 220
 requirements reports, 220
screen
 names of panels, 52
scroll bars, 55
SD tag, shop drawings
 requirements report, 214
search, 58
section
 color scheme, 132
 status boxes, 87
section numbers, 111
SectionFormat, 7, 78, 82
sections
 adding, 110, 114
 cascading windows, 127
 checking out, 237
 copy, 118
 copy from another project, 122
 creating, 110, 114
 deleting, 121
 deselecting, 103
 excluding text, 130, 131
 how to copy, 118
 how to edit in SpecLink, 44
 identifying active, 102, 103
 increasing editing speed, 237
 keyboard options for navigation,
 129
 levels, 128
 mark place, 130

- moving, 120
 - navigating, 129
 - opening, 126
 - paragraph numbering, 128
 - renumbering, 120
 - return to mark, 130
 - scrolling, 129
 - selecting, 103
 - selecting text, 130
 - SpecLink template, 111
 - styles, 128
 - tiling windows, 127
 - toolbar buttons for navigation, 129
 - viewing multiple, 127
 - sections in the PerSpective tab, 273
 - selecting sections, 103
 - selecting text, 130
 - how to, 130
 - sequence no (#), 86
 - sequential numbering style, 195
 - sequential paragraph numbering, 195
 - set paragraph margins
 - document panel ruler, 85
 - shop drawings requirements report, 214
 - Short Form hierarchy, 82
 - Short Form section contents, 326
 - Short Form tab, 42
 - show auto numbers, 60, 71
 - show level buttons, 130
 - show project paragraphs affected
 - by master updates, 266
 - source quality control requirements
 - report, 214
 - special warranty provisions
 - requirements report, 214
 - specific terms, 97
 - contractor, 97
 - default replacement, 98
 - design professional, 97
 - design-builder, 97
 - project location, 97
 - specification format
 - block style, 194
 - CSI style, 194
 - customizing, 200
 - fonts, 200
 - military style, 194
 - modify paragraph format, 200
 - page setup, 203
 - sequential numbering style, 195
 - user-defined style, 195
 - Speclink
 - project window, 52
 - SpecLink
 - about, 1
 - accessing help, 91
 - benefits, 7
 - Help, 91
 - Help window, 92
 - how to use, 44
 - key features, 6
 - main window, 50
 - navigation, document panel, 90
 - navigation, recommended, 90
 - navigation, tree panel, 90
 - navigation, window menu, 90
 - origins, 18
 - overview, 1
 - recommended workflow, 44
 - technical support, 92
 - user manual, 11
 - using for design-bid-build, 3
 - using for design-build, 2
 - using for LEED, 4
 - using help, 91
 - windows, 54
 - SpecLink section format, 330
 - SpecLink tab, 44
 - SpecLink template
 - section
 - 99999, 111
 - spell, 64
 - button on toolbar, 68
 - SQ tag, source quality control
 - requirements report, 214
 - ST tag, 249
 - standard toolbar, 67
 - start document on odd page, 204
 - starting a new project, 94
 - deselecting sections, 103
 - notes panels, 102
 - overview, 102
 - selecting sections, 103
 - status
 - included, green square, 131
 - recommended, yellow triangle, 131
 - status (S), 87
 - status bar, 55, 60
 - status boxes
 - document panel, 87
 - tree panel, 87
 - status columns
 - background color, 87
 - document panel, 86
 - style, 84
 - styles
 - customizing, 200
 - styles tab, 201
 - substantiation
 - basic concepts, 24
 - summary info, 96
 - allow BSD to publish project
 - data, 99
 - document function in
 - PerSpective, 100
 - establishing global settings, 101
 - global settings, 96
 - MasterFormat Version, 99
 - MF-04 Section ID Format, 99
 - PerSpective or Short Form, 99
 - PerSpective references, 100
 - project id, 97
 - project name, 97
 - references, 98
 - replaceable terms, 97
 - report cover sheet tab, 99
 - SpecLink, 97
 - units of measure, 99
 - system requirements
 - where to find, 12
- T**
- T, tags status column, 86
 - table borders, 221
 - table menu
 - configure column, 66
 - delete current column, 66
 - delete current row, 66
 - insert row, 66
 - insert table, 66
 - set border, 66
 - table of contents, 8, 219
 - asterisks in, 224
 - include page count in toc report, 220
 - report, 222
 - table of contents section, 225
 - tables
 - copying from Word, 156
 - delete entire table, 159
 - inserting, 158
 - tabs, 59, 159
 - tags, 60
 - button on toolbar, 85
 - how to apply, 250
 - how to view, 250
 - uses, 249
 - tags (T), 86
 - technical support, 92
 - terms and conditions of license, 332
 - test report, requirements report, 214
 - text
 - identifying active, 88
 - what will print, 88
 - text properties, 201
 - three-part section format, 330

- tile horizontally, 66, 127
 - tile vertically, 66, 127
 - title bar, 54
 - TOC. *See* table of contents
 - toggle display of master notes, 70
 - toggle display of project notes, 70
 - toggle display of project tree, 70
 - tool tips, 55
 - toolbar balloons, 55
 - toolbars, 67
 - list of buttons, 67
 - standard toolbar, 67
 - tools menu, 64
 - auto-select new paragraphs, 65
 - compare projects, 66
 - customize styles, 64
 - import from clipboard, 64
 - import from project, 65
 - look for choice fields in import, 65
 - rebuild project links, 66
 - rebuild section links, 65
 - save in-memory linking, 65
 - spell, 64
 - update ml references only, 65
 - update rs references only, 65
 - update to master, 65
 - use in-memory linking, 65
 - view updated master paragraph, 65
 - TR tag, test report requirements report, 214
 - tree menu, 60
 - down one level, 60
 - expand all, 61
 - expand branch, 61
 - expand to, 61
 - folders, 61
 - go to folder, 61
 - up one level, 60
 - tree panel, 75
 - in use by, 76, 104
 - overview, 54
 - status boxes, 87
 - two column layout, 204
- U**
- UM tag, 250
 - underline, 84
 - undo last edit, 57
 - UniFormat, 7, 81
 - units of measure
 - establishing format, 99
 - Update ML References Only, 268
 - update reminder box, 270
 - update report, 268
 - Update RS References Only, 268
- updating ML References Only, 268
- updating projects, 260
- About Your SpecLink Update, 262
 - almost completed project, 264
 - apply master paragraph updates to project, 265
 - before updating, 261
 - completed project, 263
 - Do Not Apply Master Paragraph Updates to Project, 266
 - do not update a paragraph, 267
 - facts, 260
 - instructions, 269
 - just-begun project, 264
 - LinkLine newsletter, 262
 - log file, 268
 - magenta section titles, 266
 - make project backup before updating, 268
 - office master project, 264
 - options, 262
 - preserve and mark deleted paragraphs, 265
 - print log file, 268
 - rust status columns, 266
 - sections removed from master, 264
 - show project paragraphs affected by master updates, 266
 - time, 269
 - update to master, 265
 - update to master, 268
 - view updated master paragraph, 267
- updating RS References Only, 268
- V**
- video display resolution, 55
 - view
 - buttons, 138
 - compact, 138
 - expert, 138
 - master, 138
 - using options, 138
 - view menu, 58
 - compact view, 58
 - display layout, 59
 - document links, 60
 - document panel, 59
 - expert view, 58
 - links, 59
 - master notes, 59
 - master view, 58
 - paragraph level, 60
 - project tree, 59
- project tree panel, 59
- sequence number, 59
- show auto numbers, 60
- show header/footer, 59
- status bar, 60
- tags, 60
- toolbars, 60
- view updated master paragraph, 267
- viewing a section, 126
- W**
- WE tag, warranty, executed requirements report, 214
 - what PerSpective includes, 22
 - white
 - color of status box, 88
 - widow/orphan
 - reports dialog box, 220
 - window menu, 66
 - active files list, 66
 - arrange icons, 66
 - cascade windows, 66
 - new window, 66
 - tile horizontally, 66
 - tile vertically, 66
 - windows
 - multiple, 127
 - word
 - import text from, 154
 - word processing files
 - create from SpecLink sections, 230
 - WS tag, warranty specimen requirements report, 214
 - WT tag, special warranty provisions requirements report, 214
- X**
- X, in status box, 87
 - XM tag, extra materials requirements report, 213
- Y**
- yellow
 - significance, 134
 - yellow triangle
 - significance, 88
- Z**
- zip files, 56
 - zipping a project, 235